



IN 23597-1, 23597-2 Kapesní hodinky moto W-REC bronzové, stříbrné

Pro otevřených hodinek stiskněte korunku. Pro zavření opatrně zavřete kryt.

Nastavení času:

- Vytáhněte korunku
- Otočením korunky nastavíte čas.
- Po nastavení času stiskněte korunku.

Čištění a údržba:

- Vnější část čistěte pomocí suchého a měkkého hadříku.
- Držte hodinky mimo další ostré a tvrdé předměty. Mohou hodinky poškrábat.
- Pokud hodinky nepoužíváte, uložte jej do měkkého měšce.
- Nikdy násilně neotvírejte nebo nezavírejte kryt hodinek. Můžete poškodit kryt nebo pružinu.
- Držte mimo dosah parfémů a deodorantů, obsažené chemikálie mohou poškodit kryt.
- Držte mimo dosah dětí mladších 3 let.
- Hodinky si vždy uložte do kapsy a upevněte pomocí řetězu.

IN 23597-1, 23597-2 Pocket watch moto W-REC bronze, silver

Press the crown to open the watch. Carefully close the cover to close.

Time setting:

- Pull out the crown
- Turn the crown to set the time.
- After setting the time, press the crown.

Cleaning and maintenance:

- Clean the outside with a dry, soft cloth.
- Keep the watch away from other sharp and hard objects. They can scratch the watch.
- When not in use, store the watch in a soft bag.
- Never forcibly open or close the watch cover. You may damage the cover or the spring.
- Keep away from perfumes and deodorants, the chemicals contained can damage the cover.

- Keep out of reach of children under 3 years.
- Always keep the watch in your pocket and secure it with a chain.

IN 23597-1, 23597-2 Vreckové hodinky moto W-REC bronzové, strieborné

Pre otvorenie hodiniek stlačte korunku. Pre zatvorenie opatrne zavorte kryt.

Nastavenie času:

- Vytiahnite korunku.
- Otočením korunky nastavíte čas.
- Po nastavení času stlačte korunku.

Čistenie a údržba:

- Vonkajšiu časť čistite pomocou suchej a mäkknej handričky.
- Držte hodinky mimo ďalšie ostré a tvrdé predmety. Môžu hodinky poškriabáť.
- Ak hodinky nepoužívate, uložte ich do mäkkého mešca.
- Nikdy násilne neotvárajte alebo nezatvárajte kryt hodiniek. Môžete poškodiť kryt alebo pružinu.
- Držte mimo dosahu parfumov a deodorantov, obsiahnuté chemikálie môžu poškodiť kryt.
- Držte mimo dosahu detí mladších 3 rokov.
- Hodinky si vždy uložte do vrecka a upevnite pomocou reťaze.